

New bismuth-doped silica glass for LD-pumped ultra-short-pulse laser at 1.2-micron wavelength

**Masahiro Nakatsuka, Yasushi Fujimoto, Young-seok Seo,
Takahiro Sato and Yoshiyuki Kuwada**

**ILE, Osaka university
Suita, Osaka 565-0871, Japan
naka@ile.osaka-u.ac.jp**

**presented at HEC-DPSSL meeting at LLNL, Livermore, California, U.S.A.
on May 17-19, 2006**

Abstract

LE, O saka

Bismuth doped silica glass is a new material that emits broadband fluorescence peaked around 1.25 micron with a bandwidth over 300 nm. Absorption spectra are peaked at 500 nm, 700 nm and 800 nm with broad bandwidths of about 50 nm each. The fluorescence lifetime is about 100-600 μ s depending on pump.

The fluorescence wavelength corresponds to the fiber communication band near zero-dispersion of a silica fiber. Its 800-nm absorption band makes this material potential to be pumped by the commercialized powerful laser diodes (LDs).

The LD pumped fiber amplifier at 1.3 μ m showed 10 dB gain with 5-cm length and wide-band tuned amplification through over 100-nm bandwidth.

This report will review a state-of-the-art of bismuth doped silica laser material and its possibility to use as a short pulse oscillator with an LD pumping in place of the Ti:sapphire laser.

Research background of doped-silica glass for power photonics

IL E, O saka

Issues	Parameters
Average power	High thermal shock parameter ($100 \square 5000$ W/m) silica glass, ceramics (mainly YAG)
Peak power	High laser-damage threshold silica glass
High gain	Moderate emission cross-section ($2 \square 8 \cdot 10^{-20}$ cm ²) Nd, Yb ions, disordered x'tal
Low nonlinearity	Higher Abbe number silica glass, fluorinate crystal
Low dispersion	Low index and low GVD silica glass
Scalability	Glass or Ceramics silica glass, ceramics, x'tal bonding

Laser material candidates for fusion driver in future

Nd doped silica glass

100-mm long Nd-doped silica glass



200-mm wide Nd-doped silica block by Vernueil method with zeolite-treatment

Transparent YAG ceramics


IE, Osaka

mal conductivity, it is a very good car
powerful applications such as inertial
or military devices. Yet, the maximum
quality YAG crystals for optic app
not exceed 18 cm in length and 2
r. In polycrystalline form, there is


Liquid-phase process for
powder, and
High temperature/pressure

Parameter control of Yb:YAG by cooling a material temperature


Nd:YAG, no-doped YAG, Nd/Cr:YAG



Cooled Yb:YAG laser by Prof. J. Kawanaka



$P_{\text{out}} = 75 \text{ W}$
 $\eta_{\text{slope}} = 80\%$



Zeolite-assisted Neodymium-doped silica glass


IE, O saka

Zeolite:

Any of a large group of minerals consisting of hydrated aluminosilicates of sodium, potassium, calcium, and barium. They can be readily dehydrated and rehydrated, and are used as cation exchangers and molecular sieves.

Unnecessary ions can be easily removed by chemical treatments.

Figure



Features

Five sites (S1~S5) exist in zeolite X which is occupied by ions.

There are 16 D6Rs in a unit cell. As zeolite X is dehydrated, exchanged ions tend to occupy the S1(D6R).



Crystal structure of Zeolite X is destroyed at 1000°C~, so it is expected that no crystallization occurs at sintering point (1750°C).

Zeolite X powder size is about 1μm.

Chemical treatment for ion exchange in zeolite

IE, O saka

Five sites (S1~S5) which is occupied by ions exist in zeolite X. There are 16 D6Rs in a unit cell. As zeolite X is dehydrated, exchanged ions tend to occupy the S1(D6R). Crystal structure of Zeolite X is destroyed at 1000°C~, so it is expected that no crystallization occurs at sintering point (1750°C). Zeolite X powder size is about 1μm.




We were looking for a type of poison atom to share cages in zeolite, then hit **Bismuth**.


Bismuth-doped silica glass

LE, O saka


Fluorescence



Absorption



dispersion of
silica glass fiber



zero dispersion

after Dr. S. Blair




The material features
800-nm LD pump,
broad fluorescence,
zero dispersion area,
thermally tough,
high gain

Broad absorption spectrum for LD pumping

IE, O saka

Absorption spectrum


Whole absorption spectra (dashed lines) of Bi/Al-doped silica glass for a parameter of doping rate with good agreements of fitting lines of four Gaussian peaks shown by solid lines.




Broad emission spectra for separated pump wavelength

IE, O saka


500 nm pumping




800 nm pumping



700 nm pumping



Energy diagram (tentative)




Lifetime of Bismuth fluorescence (fiber case)

LE, O saka

Lifetime of fluorescence at peak wavelength of Bi/Al-doped silica glass, a longer lifetime may results from 1150-nm band and a shorter one from 1250-nm band.

Excitation wavelength [nm]	Lifetime [μs]	Fitting
450	149 683	Double exponential
700	487	Single exponential
833	167	


(collaborative work with Nippon Sheet Glass Ltd.)



Researches on Bi-doped glasses (not finished)

years	affiliation	item	feature	refs
1996 1997	ILE, Osaka, Japan	Zeolite assisted doping of ions to silica glass	First, Nd to Qz, then, Lanthanides ions, Various ions to zeolite cages	CLEO96, J. Non-Cryst. Solids
1999 2001	ILE, Osaka, Japan	Invention of Bi ion fluorescence near 1.2 μm	Covalent by Al ions, broad fluorescence @1200nm, Broad absorption from 500-800 nm	Fusion Eng. Design, J. J. Applied Physics
2003	ILE, Osaka, Japan	Fiber amplifier for 1.3 μm communication system	Melting point control, 10dB/5cm amplification gain, 2 waves amplification	
2004	Kyushu Univ. Japan	Bi-doping in modified silica glass	Broad emission, low temperature	
2004	China	Ge oxide glass,	Low melting glass, Fluorescence origin, Bi ⁺ ,	Optics Letters
2005	Russia	Fiber amplification	MCVD, Low doping(<0.1%), 5W pump (1064nm), 400mW out, slope efficiency <14%	Quantum Electronics
2005	NSG/ILE	Fiber amp		
2005	Sumitomo, Japan	Bi-doped fiber	Low doping, Fluorescence and amplification, 190nm bandwidth @ 1.1 μm	
2005	China	Many co-dopant	Fluorescence origin, Bi ³⁺ ,	Optics Express
2005	ILE, Osaka	Co-doping with Erbium	Wide bandwidth over 550nm	Annual Report, ILE
2006	Russia	Fiber laser oscillation	Spectroscopic study	OFC/NFOEC 2006


Fiber laser @1.3 micron wavelength region



Advantage: wideband fluorescence of 300-nm bandwidth
dispersion-free region of silica glass, around 1.25 - 1.35 μm
800-nm band LD-pumping available



Characterization of Bi doped fibers

IE, O saka



Multi-wavelength amplification of Bi-fiber lasers

IE, O saka





raw material
of Bi:silica



preform of
Bi:silica fiber

QuickTimey C2
TIFFAia 8KCaUAI 8LiEVeEaEaEa
C™C±CAESENE EEC%a@CEC2C%Q...COIk6vC-C /

Bi:silica fiber
with connector



Emission-band broadening by co-doping of Erbium

IE, O saka


Bi:silica glass sample contains;

Bi/Al/Y/Ge/Ti,
pumped @800nm,
Bandwidth 350nm (6.1THz),

Bi/Al/Y/Ge/Ti/Er,
@800nm
440nm (77THz),

Bi/Al/Y/Ge/Ti/Er
@920nm
540nm (110THz)

Ti:sapphire has a FWHM-bandwidth of 180nm (86THz) peaked @790nm.



Index dispersion spectrum of Silica glass and Sapphire

IE, O saka

(A) Fused silica, (B) Schott BK7, (C) Schott SF10, (D) sapphire. after G.D. Reid & K. Wynne


(a) Data points and Sellmeier fit line.

(b) GDD for 1-mm thick material.

Dispersion property of laser media

Ti:Al₂O₃; 60 fs² @800 nm

Bi/Al:silica glass; 6 fs² @1250 nm



after G.D. Reid & K. Wynne

Issues on fabrication of Bi-Qz glass

LE, O saka

High melting temperature of quartz glass

intrinsically over **1750**□, but glass modification is available for getting lower melting point.

High vapor pressure of Bi-oxide

melting point is **1100**□, then concentration control of Bi ions is difficult.

Homogeneity of quartz glass

3-D homogenization process is needed by Shin-etsu Silica Glass.

Unknown physics of Bi-Qz glass


What is an origin of emission near 1.2 micron, **Bi⁵⁺** or Bi ³⁺ ?

Energy levels are not confirmed yet in detail.

Lifetime is very longer, **200-600 μs** than Ti ³⁺:Al₂O₃, 5 μs.

Short pulse generation of Yb doped silica fiber laser



IE, O saka



Rep. rate: 32 MHz


Pulse width: 44 fs

Band width: 58 nm
(Transform-limited: 27 fs)



Example of staging for short pulse laser system

IE, O saka



Dispersion effect of Bi:silica glass is very small, then compensation may be easy in a short optics.

Summary

IE, O saka

- 1. Volume silica glass is a candidate of average power laser material fabricated by Verneuil method**
- 2. Many fluorescent ions can be doped dispersive in silica glass by zeolite-assisted method.**
- 3. Bismuth and Aluminum ions can be co-doped in silica glass.**
- 4. Bi ion emits near infrared fluorescence, 1250-nm band, which is near zero dispersion area in a silica glass.**
- 5. Bandwidth of Bi-fluorescence is very broad, 300-550 nm. And wideband amplification was verified by the fiber amplifier experiment.**
- 6. Absorption band of Bi ions includes 800-nm region corresponding to a wavelength of high power LD pumping.**
- 7. Lifetime of Bi:silica fluorescence is 100-600 μ s.**
- 8. In conclusion, Bi:silica will work as an efficient and low-cost ultra-short pulse laser overcoming Ti:sapphire laser pumped by Nd:YAG SHG.**