





**INSTRUCTIONS FOR ADJUSTING THE INTERNAL BACK STRAPS
ON THE
ALLSEATING THEROPOD “THERAPIST” SERIES CHAIR**

- Step One: Have client get comfortable in the chair. Adjust the height of the chair and then adjust back height so it fits comfortably to the back.
- Step Two: Using the Lock out Paddle, lock the chair in an upright position. Then, using the back angle adjustment paddle set the angle of the back in a comfortable position.
- Step Three: Open up the back of the chair so that you can adjust the ergonomic strap system.
- Step Four: Release (loosen) all four straps.
- Step Five: For step 5, refer to the attached photograph.

It is very important that the client be sitting correctly and relaxed in the chair, and that they let you know the **instant they feel the support** of each strap as you adjust it.

Start with strap #1 - Pull it straight out to the side of the chair until the client feels the support. Once they have indicated they feel the support, give the strap another 1” pull and then lock it down. This strap supports the Lumbar area of the back.

Now go to strap #2 – Follow the same instructions as strap one. This strap will help support the lower back.

Now go to strap #3 – Follow the same instructions with one exception. Once the client indicates that they feel the support to the middle of the back, **STOP** pulling the strap and just lock it down. You **Do Not** give the strap the extra 1” pull.

Last, go to strap #4 – Follow the same instructions as you did for strap #3.

- Step Six: Once you have completely adjusted the straps and closed up the back of the chair, you may want to adjust the tension on the control. This knob is located under the seat. Also, you may want to adjust the arms at this time.
- Step Seven: Release the Tilt Lock (Lock Out) Paddle to allow the chair to rock