

Appendix B

Storage Precaution Signs for Hazardous Chemicals

Copies of the storage precaution signs shown in Figs. B-1, Water Reactive Chemicals; B-2, Oxidizers; B-3, Pyrophoric Substances; B-4, Toxic Compounds; B-5, Flammables; and B-6, Acids and Bases can be obtained from your ES&H team. These signs should be posted in areas where hazardous chemicals are used.

WATER REACTIVE CHEMICALS

Storage Precautions:

- Store in a cool, dry place.
- In case of fire, keep water away.

WARNING: These chemicals react with water to yield flammable or toxic gases or other hazardous conditions.



Solids

Aluminum chloride, anhydrous	Maleic anhydride
Calcium carbide	Phosphorous pentachloride
Calcium oxide	Phosphorous pentasulfide
Ferrous sulfide	* Potassium
* Lithium	* Sodium
Magnesium	

* Lithium, potassium, and sodium should be stored under kerosene or mineral oil.

Liquids

Acetyl chloride	Stannic chloride
Chlorosulfonic acid	Sulfur chloride
Phosphorous trichloride	Sulfuryl chloride
Silicon tetrachloride	Thionyl chloride

HC Hazards Control

**Lawrence Livermore
National Laboratory**

Figure B-1. Water Reactive Chemicals.

OXIDIZERS

Storage Precautions:

- Store in a cool, dry place.
- Keep away from flammable and combustible materials (such as paper, wood, etc.).
- Keep away from reducing agents such as zinc, alkaline metals, and formic acid.



Solids

Ammonium dichromate	Nitrates, salts of ⁴
Ammonium perchlorate	Periodic acid
Ammonium persulfate	Permanganic acid
Benzoyl peroxide	Peroxides, salts of ⁵
Bromates, salts of ¹	Potassium dichromate
Calcium hypochlorite	Potassium ferricyanide
Ceric sulfate	Potassium permanganate
Chlorates, salts of ²	Potassium persulfate
Chromium trioxide	Sodium bismuthate
Ferric trioxide	Sodium chlorite
Ferric chloride	Sodium dichromate
Iodates, salts of ³	Sodium nitrite
Iodine	Sodium perborate
Magnesium perchlorate	Sulfates, salts of ⁶
Manganese dioxide	

¹ Potassium bromate, sodium bromate, etc.

² Potassium chlorate, etc.

³ Sodium iodate, etc.

⁴ Ammonium nitrate, ferric nitrate, etc.

⁵ Lithium peroxide, sodium peroxide, etc.

⁶ Ferric sulfate, potassium sulfate, etc.

Liquids

Bromine	Nitric acid
Chromic acid	Perchloric acid
Hydrogen peroxide	Sulfuric acid

Gases

Chlorine	Nitrogen oxide
Chlorine dioxide	Oxygen
Fluorine	Ozone
Nitrogen dioxide	

HC Hazards Control

**Lawrence Livermore
National Laboratory**

Figure B-2. Oxidizers.

PYROPHORIC SUBSTANCES

Storage Precaution:

- Store in a cool, dry place.

WARNING: Pyrophoric substances ignite spontaneously upon contact with air.

Boron	* Iron
* Cadmium	* Lead
* Calcium	* Manganese
* Chromium	* Nickel
* Cobalt	† Phosphorous, yellow
Diborane	* Titanium
Dichloroborane	* Zinc
2-Furaldehyde	
* Finely divided metals form a pyrophoric hazard.	
† Phosphorous, yellow, should be stored and cut under water.	



LIGHT-SENSITIVE CHEMICALS

Storage Precautions:

- Avoid exposure to light.
- Store in amber bottles in a cool, dry place.

Bromine	Mercurous nitrate
Ethyl ether	Oleic acid
Ferric ammonium citrate	Potassium ferrocyanide
Hydrobromic acid	Silver salts ²
Mercuric salts ¹	Sodium iodide

¹ Mercuric chloride, mercuric iodide, etc.

² Silver acetate, silver chloride, etc.

PEROXIDE-FORMING CHEMICALS

Storage Precautions:

- Store in airtight containers in a dark, cool, and dry place.
- Label containers with receiving, opening, and disposal dates.
- Dispose of peroxide-forming chemicals before expected date of first peroxide formation in accordance with LLNL policy.
- Test for the presence of peroxides periodically.

WARNING: Under proper conditions, these chemicals will form explosive peroxides that can be detonated by shock or heat.

Acetaldehyde	Ethyl ether
Acrylaldehyde	Isopropyl ether
Crotonaldehyde	* Potassium
Cyclohexene	Tetrahydrofuran
p-Dioxane	

* Potassium peroxide often exists in the crust around a chunk of potassium. When cut with a knife, the peroxide rapidly oxidizes the residual kerosene, resulting in an explosion.



Figure B-3. Pyrophoric Substances.

FLAMMABLES

Storage Precautions:

- Store in approved safety cans or cabinets.
- Segregate from oxidizing acids and oxidizers.
- Keep away from any source of ignition: flames, localized heat, or sparks.
- Safety cans or drums containing flammable liquids should be grounded and bonded when being used.
- Keep firefighting equipment readily available.
- Have spill cleanup materials handy.
- Store highly volatile flammable liquids in a specially equipped refrigerator.



Solids

Benzoyl peroxide	Phosphorous, yellow
Calcium carbide	Picric acid

Liquids

Acetaldehyde	Ethylamine	Methyl ethyl ketone
Acetone	Ethyl benzene	Methyl formate
Acetyl chloride	Ethylene dichloride	Methyl isobutyl ketone
Allyl alcohol	Ethyl ether	Methyl methacrylate
Allyl chloride	Ethyl formate	Methyl propyl ketone
N-amyl acetate	Furan	Morpholine
N-amyl alcohol	Gasoline	Naphtha
Benzene	Heptane	* Nitromethane
N-butyl acetate	Hexane	Octane
N-butyl alcohol	Hydrazine	Piperidine
N-butylamine	Isobutyl alcohol	Propanol
Carbon disulfide	Isopropyl acetate	Propyl acetate
Chlorobenzene	Isopropyl alcohol	Propylene oxide
Cyclohexane	Isopropyl ether	Pyridine
Diethylamine	Mesityl oxide	Styrene
Diethyl carbonate	Methanol	Tetrahydrofuran
p-Dioxane	Methyl acetate	Toluene
Ethanol	Methyl acrylate	Turpentine
Ethyl acetate	Methylal	Vinyl acetate
Ethyl acrylate	Methyl butyl ketone	Xylene

Gases

Acetylene	Ethylene oxide
Ammonia	Formaldehyde
Butane	Hydrogen
Carbon monoxide	Hydrogen sulfide
Ethane	Methane
Ethyl chloride	Propane
Ethylene	Propylene

* Most nitrohydrocarbons are flammable.



Figure B-4. Flammables.

TOXIC COMPOUNDS

Storage Precaution:

- Store according to hazardous nature of chemical, using appropriate security when necessary.

WARNING: These chemicals are dangerous or extremely dangerous to health and life when inhaled, swallowed, or absorbed by skin contact. Take proper precautionary measures to avoid exposure.



Solids

Antimony compounds	Oxalic acid
Arsenic compounds	Phenol
Barium compounds	Phosphorous, yellow
Beryllium	Phosphorous pentachloride
Cadmium compounds	Phosphorous pentasulfide
Calcium oxide	Picric acid
Chromates, salts of	Potassium
Cyanides, salts of	Selenium compounds
Fluorides, salts of	Silver nitrate
Iodine	Sodium hydroxide
Lead compounds	Sodium hypochlorite
Mercuric compounds	

Liquids

Aniline	Hydrochloric acid
Bromine	Hydrofluoric acid
Carbon disulfide	Hydrogen peroxide
Carbon tetrachloride	Mercury
Chloroform	Nitric acid
Chromic acid	Perchloric acid
p-Dioxane	Phosphorous trichloride
Ethylene glycol	Sulfuric acid
Formic acid	Tetrachloroethane
Hydrazine	Tetrachloroethylene
Hydrobromic acid	

Gases

Carbon monoxide	Hydrogen chloride
Chlorine	Hydrogen cyanide
Cyanogen	Hydrogen sulfide
Diborane	Nitrogen dioxide
Fluorine	Ozone
Formaldehyde	Sulfur dioxide
Hydrogen bromide	

HC Hazards Control
Lawrence Livermore
National Laboratory

Figure B-5. Toxic Compounds.

ACIDS

Storage Precautions:

- Store in large bottles of acids on low shelf or in acid cabinets.
- Segregate oxidizing acids from organic acids and flammable and combustible materials.
- Segregate acids from bases and active metals, such as sodium, potassium, magnesium, etc.
- Segregate acids from chemicals that could generate toxic gases upon contact, such as sodium cyanide, iron sulfide, etc.
- Use bottle carriers for transporting acid bottles.
- Have Spill Control Pillows or acid neutralizers available in case of acid spills.



* Acetic acid	† Nitric acid
* Benzoic acid	Nitrous acid
* Chloroacetic acid	† Perchloric acid
† Chromic acid	* Phenol
† Hydrobromic acid	Phosphoric acid
Hydrobromous acid	Phosphorous acid
Hydrochloric acid	* Propionic acid
Hydrochlorous acid	* Sulfamic acid
Hydrofluoric acid	* Sulfanilic acid
Hydroiodic acid	† Sulfuric acid
† Iodic acid	Sulfurous acid
Muriatic acid	

* Indicates organic acids.

† Indicates strong oxidizing acids.

BASES

Storage Precautions:

- Segregate bases from acids.
- Store solutions of inorganic hydroxides in polyethylene containers.
- Have Spill Control Pillows or caustic neutralizers available for caustic spills.

Ammonium hydroxide	Calcium hydroxide
Bicarbonates, salts of ¹	Potassium hydroxide
Carbonates, salts of ²	Sodium hydroxide

¹ Potassium bicarbonate, sodium bicarbonate, etc.

² Calcium carbonate, sodium carbonate, etc.

HC Hazards Control

**Lawrence Livermore
National Laboratory**

Figure B-6. Flammables.