

# **Lawrence Livermore Laboratory**

DEVELOPMENT OF AN ACTIVELY MODELOCKED  
AND Q-SWITCHED OSCILLATOR FOR LASER  
FUSION PROGRAM AT LLL


D. J. Kuizenga

July 19, 1978

CIRCULATION COPY  
SUBJECT TO RECALL  
IN TWO WEEKS

THIS PAPER WAS PREPARED FOR SUBMISSION TO  
PROCEEDINGS OF THE CONFERENCE ON PICO-SECOND PHENOMENA,  
SOUTH CAROLINA, May 24-26, 1978

This is a preprint of a paper intended for publication in a journal or proceedings. Since changes may be made before publication, this preprint is made available with the understanding that it will not be cited or reproduced without the permission of the author.



#### DISCLAIMER

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

DEVELOPMENT OF AN ACTIVELY MODELOCKED  
AND Q-SWITCHED OSCILLATOR FOR LASER  
FUSION PROGRAM AT LLL\*

D. J. Kuizenga  
Lawrence Livermore Laboratory  
University of California  
Livermore, California 94550

The large Nd:glass laser-fusion systems such as Argus and Shiva require short-pulse oscillators that are very reliable and predictable. The requirements go well beyond what can reasonably be expected from a passively mode-locked laser. An actively mode-locked and Q-switched oscillator has now been developed that is extremely reliable and predictable, and satisfies all the requirements for the present Nd:glass laser systems. These systems require pulses that are adjustable from less than 100 ps to more than 1 ns, with less than 5% shot-to-shot variation in pulse energy and pulse width. Single-pulse energy from 100  $\mu$ J to 1 mJ is sufficient.

An actively mode-locked CW Nd:YAG laser can provide the range of short pulses required [1,2] and is also sufficiently stable. It has been shown that under steady-state conditions the pulse width in this laser, mode-locked with an amplitude modulator, is given by:

$$\tau_p = \frac{(2 \ln 2)^{1/2}}{\pi} \frac{(g_0)^{1/4}}{\theta_m^{1/2}} \frac{1}{(f_m \cdot \Delta f)^{1/2}}, \quad (1)$$

where

$\theta_m$  = depth of modulation

$g_0$  = round-trip amplitude gain

$\Delta f$  = linewidth

$f_m$  = modulation frequency

For typical laser parameters, pulses shorter than 100 ps can be obtained; and with the use of an etalon in the cavity, longer pulses of up to 1 ns or more can be obtained, depending on the cavity length.

\*Work performed under the auspices of the U.S. Department of Energy,  
Contract W-7405-eng-48.

A typical CW mode-locked Nd:YAG laser gives only a few nanojoules in a single short pulse. This can be increased by more than four orders of magnitude by simultaneously Q-switching the laser. However, the buildup time in a typical Q-switched laser is not long enough for the short-pulse generation process to reach steady state. To obtain good mode locking in the Q-switched Nd:YAG laser, the buildup time of the Q-switching has to be increased. Several workers [4-7] have developed techniques to do this in an attempt to obtain steady-state mode locking before the Q-switched pulse train is obtained.

We have now further developed a method that allows the mode-locking process to go to its steady state condition before the laser is Q-switched.[8] This is done by pumping the laser quasi-cw for about 5 ms. During this time, the loss in the Q-switch is such that the laser will just slightly go above threshold. The active modulator is on during this time, and the laser oscillates quasi-cw for a period long enough to obtain stable transform-limited short pulses. At the end of this prelude period, the laser is Q-switched, and a train of stable, short pulses is obtained.

Three conditions have to be satisfied during this prelude period. First, the short pulse envelope has to approach a steady state value. It has been shown [3] that the pulses are within 5% of the steady state value after a number of round trips  $M$  given by:

$$M = \frac{0.38}{g^{1/2} \theta_m} \left( \frac{\Delta f}{f_m} \right), \quad (2)$$

where  $g$  is the roundtrip amplitude gain during the prelude period, and the other parameters are defined for (1). The dominating factor here is  $f/f_m$ , which is typically on the order of  $10^3$ , and hence for a typical mode-locked Nd:YAG laser, it takes about 10 to 100  $\mu$ s for the short pulses to approach their steady-state value. This is easily satisfied during the prelude period.

The prelude period must also be long enough for the pulses to become transform-limited. It may happen that even though the short pulse envelope has reached its steady state value, the pulse still has considerable substructure and may be chirped, etc. This type of substructure is smoothed out by repeated passes through the finite bandwidth of the active medium (or etalon). If one considers the narrowing of the spectrum on repeated round trips, it can be shown that the spectrum is within a factor of two from the steady state, transform limited spectrum after a number of round trips  $M$  given by:

$$M > \frac{0.5}{g^{1/2} \theta_m} \left( \frac{\Delta f}{f_m} \right). \quad (3)$$

This is essentially the same as the condition for the short pulse envelope to reach steady state. A much more severe condition to obtain perfect transform limited pulses is given by:

$$M > \frac{0.35}{g} \left( \frac{\Delta f}{f_{ax}} \right)^2, \quad (4)$$

where  $f_{ax}$  is the axial mode spacing of the cavity. This is the condition required to get single axial mode operation without modulation. With the modulator on, this condition means that we get this single axial mode plus its sidebands produced by the modulator, and hence a perfect transform limited pulse. For a typical mode-locked Nd:YAG laser, it can take as much as several milliseconds to satisfy this condition. This condition is more severe than is actually required to get good pulses from a Nd:YAG laser.

Finally, when the laser goes above threshold at the start of the pre-lase period, there are the usual relaxation oscillations. These have to die out so that the laser can oscillate quasi-cw. It usually takes a few upper level lifetimes for this to happen and hence in a Nd:YAG laser, these relaxation oscillations die out in about 1 ms. In practice it is found that a pre-lase period of about 3 to 5 ms gives very good operation of this type of laser.

A typical arrangement for this type of oscillator now in operation on Argus and Shiva is shown in fig. 1. An acousto-optic modulator and Q-switch were used. The modulator, as well as the Q-switch, had direct water cooling of the transducer ( $35^\circ$  Y cut LiNbO<sub>3</sub>) to ensure stable thermal conditions in the modulator. The modulator and Q-switch, as well as the Nd:YAG rod, were all cut as Brewster's angle to completely eliminate any spurious etalon effects or multiple reflections between components in the laser cavity. This gave stable and predictable short pulses from this laser, and also reduced the noise level between pulses to a minimum.




Fig.1 Typical arrangement of modelocked and Q-Switched Nd:YAG laser. Pulse repetition rate is 5 or 10 pps.

It was quite difficult to obtain stable, quasi-CW pumping of the lamps to satisfy the  $\pm 5\%$  stability of the pulse energy. The final and successful arrangement consisted of a bank of power transistors to regulate the voltage of a number of capacitors. In addition, a transistor bank in series with the lamps provided feedback regulation of the simmer and peak currents through the lamps adjustable from 1 to 5 ms and shot-to-shot stability of better than 0.3%. This was sufficient to give good operation of the laser.

We found that the pre-lase signal is a very good indicator of how well the laser is mode-locked [8]. It was found that with the modulator off, the initial relaxation oscillations are quite irregular; but with the modulator on, these relaxation oscillations become very smooth and regular. For a small change in cavity length ( $\sim 25 \mu\text{m}$ ) the relaxation oscillation continues

through the entire pre-lase period. These driven oscillations occur for length changes longer and shorter than the optimum length. It is precisely the combination of these characteristics that allows one to easily adjust the laser for optimum mode locking, and one only needs a very slow detector and oscilloscope to do this. Many other laser problems can be diagnosed from this pre-lase period, such as higher-order transverse modes.

An optical correlator was used to measure the pulse widths from the Argus laser. Although in principle similar to that described before [3] this correlator was considerably improved to routinely do very accurate short-pulse measurements. Figure 2 shows the range of short pulses available from this oscillator. Note that with the aid of a 2.5 mm and 11 mm uncoated quartz etalon, the required pulsewidth range from 100 ps to 1 ns can be obtained. Figure 3 shows the energy in a single, selected pulse near the peak of the pulse train. For strong modulation, there is some reduction in output




Fig.2 Range of pulses available from Argus Oscillator.




Fig.3 Single pulse energy from Argus Oscillator.

The stability of these oscillators is very good. Typically, over the duration of one hour, the variation of a single selected pulse is less than  $\pm 2\%$ . For the Shiva Oscillator, we have also introduced a new method to switch out a single pulse. We found that the time from when the laser is Q-switched, to a single pulse at the peak of the pulse train is stable to less than one roundtrip in the cavity. Hence we can select this single pulse after a fixed time delay from Q-switching the laser. An avalanche transistor stack is used to drive the KD\*P Pockells Cell to select a single pulse. Typically, two or three stages are used in the pulse selector to obtain sufficient pre-pulse isolation.

## REFERENCES

1. D. J. Kuizenga and A. E. Siegman, IEEE J. Quant. Electron. QE-6, 694 (1970)
2. D. J. Kuizenga and A. E. Siegman, IEEE J. Quant. Electron. QE-6, 709 (1970).
3. D. J. Kuizenga, D. W. Phillion, T. Lund, and A. E. Siegman, Opt. Commun. 9, 221 (1973).
4. G. V. Krivoshechekov, L. A. Kulevskii, N. G. Nikulin, V. M. Semibalamut, V. A. Smirnov, and V. V. Smirnov, Sov. Phys. JETP 37, 1007 (1973).
5. G. V. Krivoshechekov, N. G. Nikulin, and V. A. Smirnov, Sov. J. Quant. Electron. 5, 1096 (1976).
6. I. V. Tomov, R. Fedosejevs, M. C. Richardson, and W. J. Orr, Appl. Phys. Lett. 29, 193 (1976).
7. I. V. Tomov, R. Fedosejevs, and M. C. Richardson, Appl. Phys. Lett. 30, 164 (1977).
8. D. J. Kuizenga, Opt. Commun. 22, 156 (1977).

## NOTICE

"This report was prepared as an account of work sponsored by the United States Government. Neither the United States nor the United States Department of Energy, nor any of their employees, nor any of their contractors, subcontractors, or their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness or usefulness of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately-owned rights."

Reference to a company or product names does not imply approval or recommendation of the product by the University of California or the U.S. Department of Energy to the exclusion of others that may be suitable.