

Application of X-ray Lasers to Probe High Density Plasmas*

UCRL-JC-124048 Abs

L.B. Da Silva, T.W. Barbee, Jr., R. Cauble, P. Celliers, D.H. Kalantar, M.H. Key, S. Libby,
D.L. Matthews, J.C. Moreno, J.E. Trebes, A.S. Wan and F. Weber
Lawrence Livermore National Laboratory, Livermore, CA;

The reliability and characteristics of collisionally pumped soft x-ray lasers make them ideal for a wide variety of plasma diagnostics. These systems now operate over a wavelength range extending from 35 to 400 Å and have output energies as high as 10 mJ in 150 ps pulses. The beam divergence of these lasers is less than 15 mrad and they have a typical linewidth of $\Delta\lambda/\lambda \sim 10^{-4}$ making them the brightest xuv sources available. In this talk I'll describe our use of x-ray lasers to probe high density plasmas using a variety of diagnostic techniques. Taking advantage of recently developed multilayer beamsplitters we have constructed and used a Mach-Zehnder interferometer operating at 155 Å to probe 1-3 mm size laser produced plasmas with peak electron densities of $4 \times 10^{21} \text{cm}^{-3}$. A comparison of our results with computer simulations will be presented. We have also used x-ray lasers and a multilayer mirror imaging system to study hydrodynamic imprinting of laser speckle pattern on directly driven thin foils with 1-2 μm spatial resolution. Results from these experiments as well as our use of x-ray laser moiré deflectometry to measure the electron density profile in ICF hohlraums will be discussed.

*Work performed under the auspices of the U. S. Department of Energy by LLNL under contract number W-7405-ENG-48 .

Abstract Submitted for the
23rd IEEE International Conference
on Plasma Science

June 3-5, 1996
Boston, Massachusetts USA



Subject Topic: Laser produced

plasmas

Subject Number: 4.1

- ☒ Prefer Oral Session
☐ Prefer Poster Session
☐ No preference
☐ Special requests for placement
of this abstract:

☐ Special requests for equipment:

Submitted by:

Signature

Typed Name

Luiz Da Silva

Institution/Company

Lawrence Livermore Nat'l Lab

Address

1151-399, P.O. Box 808

City, State/Province, Zip Code

Livermore, CA 94550

Country

USA

Telephone

(510) 423-9867

Fax

(510) 424-2778

Send the original abstract
and two copies to:

Professor Chung Chan
ICOPS '96 Conference Chairman
Northeastern University
328 Dana Research Center
Boston, MA 02115 USA

Abstract must be received no later
than Friday, February 9, 1996